

SPA CARE AND MAINTENANCE

Draining Your Spa

WARNING!

To prevent damage to spa's components, turn off power before draining it. Do not turn the power back on until your spa has been refilled. Drain valve will drain approximately 5 gallons of water per minute.

Step 1



Your drain valve is located in front of your spa next to your access door panel. Pull out the fitting with your finger as shown in step 2.

Step 2



Pull the drain valve outward, and you might have to twist the fitting slightly back and forth to pull it out all the way as shown in step 3.

Step 3



Remove the outside cap and attach garden hose to drain valve.



Attach garden hose to fitting.

Step 4



Drain Valve is shown fully open



After the drain valve is attached to drain fitting, push the drain valve back in as shown in Step 4. When the spa is drained, pull the valve outward and remove hose. Replace cap and tighten. Push the drain valve back in all the way as shown in step 1.